



ARM-EVAC® 50 Optional Dual Arm Attachment



Kit Contents: One (1) Arm Adaptor
 Two (2) Flex Arms
 One (1) Blanking Cap (Not shown)

Fitting Instructions:

1. Ensure Arm-Evac 50 is switched off and is disconnected from power outlet.
2. Lift Arm-Evac 50 unit and place Arm Adaptor into opening of Arm-Evac 50 as shown in fig 1.
3. Snap fitting upwards so that the Plenum opening on the Arm-Evac 50 slots into the groove on the Arm Adaptor.
4. Push fit Extraction Arm(s) into outlet(s) on Arm Adaptor. If only one Extraction Arm is required, use Blanking Plug supplied to block other outlet.
5. Position Extraction Arm(s) as required. (See Fig. 2)
6. Follow steps 1, 2 & 3 of Plenum Operation (contained in Arm-Evac 50 Operating Manual)
7. The unit is now ready for use.



Fig. 1 Slot Arm Adaptor into Plenum Opening



Fig.2 Arm-Evac 50 with Dual Arm Attachment



PACE Incorporated
255 Air Tool Drive
Southern Pines,
North Carolina, 28387
Tel: (877) 882-PACE
Tel: (910) 695-7223
Fax: (910) 695-1594

Pace Europe
11 Holdom Avenue
Bletchley, Milton Keynes,
United Kingdom, MK11QU
Tel: 011 44 1908 277666
Fax: 011 44 1908 277777